COOKTOP AND MANIFOLD PARTS

For Model: FGP210KQ0, FGP210KN0
(Designer White) (Almond)

20" GAS
FREESTANDING RANGE
PILOT IGNITION
STANDARD CLEAN OVEN

Roper™
BY WHIRLPOOL CORPORATION



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COOKTOP AND MANDIFOLD PARTS

For Model: FGP210KQ0, FGP210KN0
(Designer White) (Almond)

Illus. No.	Part No.	DESCRIPTION
1		Literature
	LIT4364041	Use & Care Guide
2	4364146	Grate (4)
3	4364371	Tubing, Top Pilot
4		Overlay, Manifold
	8189743	Black
	8189744	White
5	4364132	Cover, Pilot
	4364151	Screw 8−18 x 3/8
6		Cooktop
	4364266	White
	4364271	Almond
7	4364262	Support, Burner
	4364153	Screw 10−12 x 1/2
8	4364260	Burner, Top Rear
9	4364261	Burner, Top Front
11		Knob, Burner
	4364479	Black
	4364480	White
12	4364157	Strike Pin W/Nut
13	4364159	Pressure Regulator
14	4364263	Pipe, Manifold
15		Panel, Manifold (Includes #4)
	4364270	Black
	4364398	White
16	4364162	Valve, Burner (Includes No.32)
17	4364264	Support, Manifold
	4364153	Screw, 10−12 x 1/2
18	4364124	Loxit Fitting 3/16
19	4364164	Loxit Fitting 3/8"
20		Knob, Thermostat
	4364477	Black
	4364478	White
21	4364125	Thermostat, Oven (Includes No. 31)
22	4364168	Valve, Safety
	4364153	Screw, 10−12 x 1/2
23	4364127	Pilot, Oven Burner
24	4364170	Burner, Oven
	4364171	Screw, 10−24 x 5/8
26	4364038	Tubing, Oven 3/8" O.D.
27	4364039	Tubing, Pilot 3/16" O.D.
31	4364167	Bolt, Thermostat
32	4364173	Bolt, Valve Mtg.
34	4364042	Flame Spreader
37	4364046	Wingnut
39	4364158	Catch, Strike Pin

OVEN PARTS

For Model: FGP210KQ0, FGP210KN0
(Designer White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Model: FGP210KQ0, FGP210KN0
(Designer White) (Almond)

Illus. No.	Part No.	DESCRIPTION
1	4364212	Brace, Back
3	4364267	Bottom, Burner Box
5	4364268	Flue Box
6	4364075	Ring, Flue Box
7	4364199	Bottom, Main
9	4364269	Main Back
10	4364204	Insulation, Back
11	4364205	Insulation, Wrap
14	4364080	Leveler Leg (4)
15		Panel, Side
	4364201	White
	4364202	Almond
16	4364084	Gasket, Oven Top
17	4364208	Gasket, Oven Side
18	4364210	Rack, Oven
19	4364272	Bottom, Oven
20	4364209	Frame, Front
26	4364088	Anti−Tip Bracket
37		Support, Side
	4364214	Left
	4364215	Right
38	4364130	Clip, Thermo Bulb
42	4364279	Box, Power

OVEN DOOR AND BROILER PARTS

For Model: FGP210KQ0, FGP210KN0
(Designer White) (Almond)



Illus. No.	Part No.	DESCRIPTION
1	8189585	Liner, Door
3		Panel, Oven Door
	8189800	White
	8189801	Almond
4		Bearing, Hinge
	4364237	Left
	4364238	Right
5		Hinge, Door
	4364235	Left
	4364236	Right
6	4364234	Spring, Door
7	4364284	Insulation, Door
8	4364285	Panel, Inner Door
9	4364276	Liner, Brlr Drawer
12		Panel, Broiler Door
	4364379	White
	4364287	Almond
13		Handle, Drawer
	4364054	Black
	4364399	White
14	4364055	Spacer, Handle
	4364057	Screw, 10−24 x 3/8
16	4364060	Spring, Broiler
17		Broiler Drawer Runner
	4364061	Left
	4364062	Right
18	4364273	Liner, Broiler
19	4364216	Broiler Pan
20	4364065	Grille, Broiler
21		Hinge, Broiler
	4364066	Left
	4364067	Right
	4364068	Screw, 10−24 x 3/8
	4364069	Hex Nut, 10−24
24	4364233	Rod, Oven Door
25	4364123	Glide, Broiler Pan
26		Handle, Oven Door
	4364232	Black
	4364394	White
28	4364275	Insulation, Broiler Drawer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BACKGUARD PARTS

For Model: FGP210KQ0, FGP210KN0
(Designer White) (Almond)



Illus. No.	Part No.	DESCRIPTION
1		Backguard
	4364446	White
	4364443	Almond
2	4364046	Wingnut, 10 x 24
3	4364102	Hinge Pin (2)